

*E. J. Family*

# **RADION**

## **MODEL FSM 5000 VHF-UHF**

### **Portable Field Strength Meter**



Instrument Serial Number 3865

## **OPERATING INSTRUCTIONS**

**THE RADION CORPORATION**

1130 W. Wisconsin Avenue

Chicago 14, Illinois, U.S.A.

MOhawk 4-4617

# TABLE OF CONTENTS

	page
SPECIFICATIONS .....	3
SECTION I. GENERAL DESCRIPTION .....	3
1. Introduction .....	3
2. Accuracy .....	3
3. Batteries .....	3
4. Accessory Equipment .....	3
SECTION II. OPERATION .....	3
PART A. Installation of Batteries .....	3
1. Installation Procedure .....	3
2. Battery Checking .....	4
PART B. Measurement of Signal Levels .....	4
1. Antenna Connections .....	4
2. Measurement of Absolute Values of Received Signals .....	4
3. Measurement of Relative Values of Received Signals .....	4
SECTION III. BASIC USES .....	4
1. Determining Antenna Location .....	4
2. Selecting Best Antenna for a Given Location .....	4
3. Locating TVI .....	4
4. Trouble Shooting TV Receivers .....	5
5. Checking Oscillator Radiation .....	5
6. Determining Impedance Matching in Lead-ins .....	5
SECTION IV. MAINTENANCE .....	5
1. Warranty .....	5
2. Weak Batteries .....	5
3. Trouble Shooting the FSM 5000 .....	5
4. Parts List .....	8
ILLUSTRATIONS	
Fig. 1. Chassis Top View .....	6
Fig. 2. Chassis Bottom View .....	6
Fig. 3. Schematic Diagram .....	7

